


Door lock installation VIII



No	Parts number	Parts name	Quantity
1	AZ1642340022	Lock pin bracket	2
2	AZ1642340023	Lock pin bracket Pad	2
3	AZ1642340020	Auxiliary support	2
4	AZ1642340024	Lock pin	2
5	AZ1642340021	Auxiliary support pin	2
6	Q2560820	Screw	4
7	Q2540820	Screw	8

Process content:

- 1 Apply glue to the thread surface before assembling the auxiliary support pin to the door;
- 2 the auxiliary support is assembled to the body;
- 3 The combination of the lock pin bracket and the bracket is assembled to the door.