



NO	Parts number	Parts name	Quantity
1		Steering column assembly	1
2	AZ1642160217	Steering column under guard	1
	AZ1642930620	Combination screw	5

Note: 1. After the steering column lower shroud is assembled, install the steering column cover (rear) and the steering column adjustment handwheel;

2. The lower left side of the steering column is not installed at the left front side and fixed together with the footrest.